


W-3A Sokol

detail set for ANSWER 1/48 kit • sada detailů pro stavebnici ANSWER 1/48



- APPLY EXPRESS MASK AND PAINT BEFORE GLUING
POUŽIT EXPRESS MASK NABARVIT PŘED SLEPENÍM
- SYMMETRICAL ASSEMBLY
SYMETRICKÁ MONTÁŽ
- REMOVE
ODSTRANIT
- GRIND
OBROUSIT
- DRILL HOLE
VRTÁT OTVOR
- BEND
OHNOUT
- OPTION
VOLBA
- REPLACE
NAHRADIT
- 1** COLORED ETCHED PARTS
LEPTANÉ BAREVNÉ DÍLY
- 1** ETCHED PARTS
LEPTANÉ NEBAREVNÉ DÍLY
- 1** ORIGINAL KIT PARTS
PŮVODNÍ DÍLY STAVEBNICE

ORIGINAL KIT PARTS PŮVODNÍ DÍLY STAVEBNICE	PHOTO-ETCHED PARTS LEPTANÉ DÍLY	PARTS TO BE REMOVED DÍLY K ODSTRANĚNÍ	FILL TMELIT
---	------------------------------------	--	----------------

Diagram 1 (Top Left): Shows the assembly of the seat backrest (F32) and seat (F27). Part 10 (PE9) is attached to the backrest. Part 8 (PE6) is attached to the seat. Part 11 (PE8) is attached to the seat base. Part 11 is also shown being bent (11).

Diagram 2 (Top Right): Shows the assembly of the desk (PE4). Part 9 (PE2) is attached to the desk. Part 12 (PE1) is attached to the desk.

Diagram 3 (Middle Right): Shows the assembly of the desk (PE4) with part 5 and part 7.

Diagram 4 (Bottom Right): Shows the assembly of the keyboard (D8, D11) and control panel (3, PE2). Part 4 is attached to the keyboard. Part 6 is attached to the control panel. Part 3 (PE2) is attached to the control panel.

Diagram 5 (Bottom Left): Shows the assembly of the control panel (G8, H12). Part 1 (PE22, PE23) is attached to the control panel. Part 2 is attached to the control panel. Part 19 is attached to the control panel.